

WHAT TO USE



PLASTIC SURFACES
use neutral detergent on soft cloth.



TOUCH SCREENS/ SCREENS use 70% alcohol wipes.



DETERGENTS WITHOUT ethyl alcohol, bleach or alkaline agents.

WHAT TO DO



WASH YOUR HANDS
before and after cleaning your device.



APPLY ON SOFT CLOTH
then wipe the device surfaces.



DISPENSE WIPES & CLOTHS
after using.

WHAT NOT TO DO



SPRAY DIRECTLY
on the screen.



USE PAPER tissues, paper towels, or toilet paper to wipe.



POUR EXCESS AMOUNT OF LIQUID
On the cloth.

 We recommend twice daily cleaning. Always test a small area before using and follow manufacturer's instructions.

